

Seriously Pro

Racing F3 Flight Controller



Thank you for directly supporting the Cleanflight project with your purchase.

About

The Seriously Pro Racing F3 Flight Controller (SPRacingF3) was designed to give awesome flight performance based on tried and tested sensors whilst also providing unparalleled I/O capabilities in a small and extremely lightweight form-factor using a next-generation CPU.

The SPRacingF3 gives you all the features you need for the heart of your aircraft, whether you're into FPV racing, acrobatic flying or aerial photography it's perfect.

Features

- No compromise I/O. Use all the features all the time; e.g. Connect your OSD + SmartPort + SBus + GPS + LED Strip + Battery Monitoring + Sonar + 8 motors - all at the same time!
- On-board high-capacity black box flight log recorder - optimize your tuning and see the results of your setup without guesswork (Acro and Deluxe).
- Next-generation STM32 F3 processor with hardware floating point unit for efficient flight calculations and faster ARM-Cortex M4 core.
- Stackable design - perfect for integrating with OSDs and power distribution boards.
- 16 PWM I/O lines for ESCs, Servos and legacy receivers. 8 available on standard pin headers. 8 via side mounted connectors.
- Full support for OneShot ESCs for easy PID tuning and a sharper response.
- Supports SBus, SumH, SumD, Spektrum 1024/2048, XBus, PPM, PWM receivers. No external inverters required (built-in).
- Dedicated output for programmable LEDs - great for orientation, racing and night flying.
- Dedicated I2C port for connection of OLED display without needing flight battery.
- Battery monitoring ports for voltage and current.
- Sonar support for precision low-altitude hold.
- Buzzer port for audible warnings and notifications.
- Developer friendly debugging port (SWD) and boot mode selection, unbrickable bootloader.
- Symmetrical design for a super tidy wiring.
- Wire up using pin headers, JST-SH sockets or solder pads. Use either right-angled or straight pin-headers.
- Barometer mounted on the bottom of the board for easy wind isolation.
- Loop times up to ~2x as fast as previous-generation STM32F1 based boards.
- Configuration of the flight controller via a cross-platform GUI (Windows/OSX/Linux).
- Supports a variety of aircraft, tricopters, quadcopters, hexacopters, octocopters, planes and more.
- Available in Acro and Deluxe versions.

Variations

Acro: Standard model for racing/acro flying.

Deluxe: Additional sensors for altitude and direction.

Software

The SPRacingF3 runs the open-source Cleanflight flight control (FC) software which has an ever-growing community of friendly developers and users. Being open-source means that you too can contribute to the system.

Cleanflight comes with a detailed manual that is reviewed and maintained by the Cleanflight developers and community. No more out-of-date wiki pages and second-hand information.

See <http://cleanflight.com> for links to the manual. PDF copies can be downloaded from the github releases pages. Ensure you reference the manual that is appropriate to your firmware version.

History

The hardware was designed by the lead developer of Cleanflight, Dominic Clifton, to be more capable than the STM32F1-based boards after hearing feedback from the Cleanflight users, contributors and top-pilots.

WARNINGS

Failure to adhere to these warnings will void your warranty and destroy your flight controller.


- Observe polarity at ALL TIMES. **Check** and **DOUBLE CHECK** before applying power.
- **POWER OFF** before unplugging, plugging in or making any connections.
- Connect only one SOURCE of power to the **VCC** pins / Do not connect more than one source of power to two or more of the **VCC** pins. e.g. If you are using ESCs with BECs then remove the center **RED** wire from all but one ESC connector.
- Do not connect GND, **VCC** or **3.3v** to each other (short circuit).
- Do not connect GND, **VCC** or **3.3v** to any inputs or outputs unless specifically stated.
- Do not connect any input or output to any other input or output unless specifically stated.
- The **3.3v** supply is for low-current use only. 100mA MAX.
- Do not allow dirt/dust/glue/etc into the pressure sensor (barometer).
- Keep magnets away from the flight controller.

GENERAL ADVICE

Follow the advice below for best performance and long-life of your flight controller:


- Apply resin/glue to reinforce JST-SH connectors - helps if you crash your aircraft.
- Using an enclosure/box for the flight-controller is recommended.
- Install open-cell foam under the pressure sensor - sandwich some between the FC and frame.
- Route motor/battery wires as far away from the compass sensor (magnetometer) as possible.
- Only install the BOOT jumper pins if you need them.
- Using color coded pin headers is recommended (not supplied), especially for VBAT headers.
- Do everything you can to prevent vibrations reaching the accelerometer/gyro sensor. e.g. balance props, motors and secure everything.

TOP



1. SWD Debugging connector
2. UART2 connector
3. Micro USB socket
4. UART3 headers
5. UART1 headers
6. IO_1 connector
7. IO_2 connector
8. Battery voltage monitoring headers
9. Buzzer headers
10. ESC / Servo output headers
11. Boot headers

- A. Power LED
- B. Status LED
- C. Orientation indicator
- D. Accelerometer & Gyro sensor
- E. Magnetometer (Compass sensor, Deluxe Only)
- F. 8Mb Flash Storage
- G. STM32F303 processor with FPU
- H. M3 mounting hole



SWD/DEBUG (1)		UART2 (2)	
1 ● GND	1 ● GND	1 ● GND	1 ● GND
2 NRST	2 VCC	2 VCC	2 VCC
3 SWDIO	3 TXD/SWDCLK	3 TXD	3 TXD
4 SWDCLK	4 RXD	4 RXD	4 RXD

SWD/DEBUG connector - Used for software development or flashing via SWD

Cannot be used when UART2 is enabled. Use an ST-Link debugger with OpenOCD or a J-Link debugger.

UART2 connector - Used for 5.0v Serial IO. (GPS, etc.)

MUST NOT be used when SWD port is in use.

UART3 (4)		UART1 (5)	
1 ■ GND	1 ■ GND	1 ■ GND	1 ■ GND
2 ● VCC	2 ● VCC	2 ● VCC	2 ● VCC
3 ● TXD	3 ● TXD	3 ● TXD	3 ● TXD
4 ● RXD	4 ● RXD	4 ● RXD	4 ● RXD

UART3 headers - Used for 3.3v Serial IO. (Serial RX, etc.)

MUST NOT be used when PWM RX is in use. **MUST NOT** be used at the same time as IO_2 CH3/4.

UART1 headers - Used for 5.0v Serial IO. (OSD, etc.)

MUST NOT be used when a cable is connected to the USB port.

IO_1 (6)	
1 1 GND	1 1 GND
2 2 VCC	2 2 VCC
3 3 CH1 / PPM	3 3 CH1 / PPM
4 4 CH2 / GPIO	4 4 CH2 / GPIO
5 5 CH5 / GPIO	5 5 CH5 / GPIO
6 6 CH6 / GPIO	6 6 CH6 / GPIO
7 7 LED_STRIP	7 7 LED_STRIP
8 8 3.3v	8 8 3.3v

IO_1 connector - PWM RX / PPM RX / GPIO / LED Strip

When using a PWM receiver connect CH1/2/5/6 to PWM RX.

LED Strip data signal can be used to change individual colors of each LEDs on a strip of WS2812 RGB leds - Perfect for battery warning lights, orientation lights, indicators, failsafe, display flight modes, etc.

CH1/2/5/6 can be used as a general purpose IOs when not used for PPM/PWM RX.

A 3.3v output is also available.

IO_2 (7)	
1 1 GND	1 1 GND
2 2 VCC	2 2 VCC
3 3 CH3 / RXD	3 3 CH3 / RXD
4 4 CH4 / TXD	4 4 CH4 / TXD
5 5 CH7 / SONAR TRIGGER	5 5 CH7 / SONAR TRIGGER
6 6 CH8 / SONAR ECHO	6 6 CH8 / SONAR ECHO
7 7 ADC_1 / CURRENT METER	7 7 ADC_1 / CURRENT METER
8 8 ADC_2 / RSSI	8 8 ADC_2 / RSSI

IO_2 connector - Serial RX / PWM RX / GPIO / UART3

When using a PWM receiver connect CH3/4/7/8 to PWM RX.

When using a 3.3v Serial RX receiver (S.Bus, SUMD/H, etc.) use GND/VCC/CH3 (UART3 RX).

CH3/4/7/8 can be used as general purpose IO when not used for Serial/PWM RX.

CH7/8 can be used for a 3.3v Sonar sensor when not used for PWM RX.

ADC_1/2 can be used to connect Battery Current Monitoring and RSSI signals. (3.3v MAX).

VBAT (8)	
1 1 GND / BATTERY NEGATIVE -	1 1 GND / BATTERY NEGATIVE -
2 2 BATTERY POSITIVE +	2 2 BATTERY POSITIVE +

VBAT headers - Connect flight battery for voltage monitoring, logging and warnings

WARNING: DOUBLE CHECK POLARITY!

BUZZER (9)	
1 1 BUZZER -	1 1 BUZZER -
2 2 VCC / BUZZER +	2 2 VCC / BUZZER +

Buzzer headers - Connect to a buzzer for warnings and notifications

Use a low-power ~50mA 5.0v buzzer that only requires power to produce sound, e.g. Sonicrest HCM1205X. See Cleanflight manual for links. Can also be used to find your aircraft after a crash.

OUTPUTS 1 - 8 (10)	
1 -	1 -
2 + VCC	2 + VCC
3 S SIGNAL	3 S SIGNAL

OUTPUT headers - Connect up to 8 motors and/or servos

Currently supports PWM ESCs (400hz default), Oneshot 125 ESCs and PWM servos (50hz default).

WARNING: Configure outputs before connecting power to servos and ESCs.

BOOT (11)	
1 ● 3.3v	1 ● 3.3v
2 ● BOOT	2 ● BOOT


Boot Headers - Used for recovering firmware

No connection = Boot Normally

Bridged = STM32 Bootloader

BOTTOM

1. UART1 connector
2. I2C1 connector
3. ADC pads (Current, RSSI)
4. PPM & GPIO pads
5. SONAR pads
6. LED_STRIP & 3.3v pads



A. Barometer (Pressure sensor, Deluxe Only)

UART1 (1)	
1	GND
2	VCC
3	TXD
4	RXD

UART1 headers - Used for 5.0v Serial IO. (OSD, etc.)

MUST NOT be used when a cable is connected to the USB port.

MUST NOT be used at the same time as the UART1 headers.

I2C1 (2)	
1	GND
2	5.0v
3	SCL
4	SDA

I2C1 connector - Used for external sensors and OLED displays.

The SCL and SDA are 3.3v signals.

5.0v is always supplied via the on-board voltage regulators, even when powering via USB.

WARNING: logic level converters are **REQUIRED** if your sensors require 5.0v signals.

SOLDER PADS (3)	
■	CH1 / PPM
■	CH2 / GPIO
■	ADC1 / RSSI
■	ADC2 / CURRENT METER
■	CH7 / SONAR TRIGGER
■	CH8 / SONAR ECHO
■	LED_STRIP
■	3.3v

Solder pads

Use instead of the JST-SH connectors as-required.

NOTE: Good soldering skills required.

Soldering

IMPORTANT:

- Use a high quality soldering iron and good solder.
- Tin/Lead solder is **MUCH** easier to use other Lead-free solder.
- Use solder with flux and remove any flux residue after soldering.
- Ensure you have sufficient fume extraction when soldering.
- Pin headers that connect to the GND signal will be more difficult to solder because the PCB will sink the heat from your soldering iron.
- If you have never soldered before then **DO NOT** attempt to solder the flight controller, practice on something else first.

The flight controller is supplied with a bag of pin-headers. Some are straight, some are right-angled. Choose **very carefully** which ones you want to use. You can solder headers to top or the bottom of the board.

Once you have soldered pin headers in place **DO NOT** attempt to remove them unless you are **highly skilled** in de-soldering and have the correct tools.

Cables

The flight controller is supplied with two 8-pin JST-SH cables and two 4-pin JST-SH cables. The 8-pin JST-SH cables are for the IO_1 and IO_2 connectors. The 4-pin JST-SH cables are for any of the UART1/2/SWD/I2C1 connectors.

NOTE: the colors of each wire may change due to manufacturing and supplier variances.

The two 8-pin JST-SH cables have one 3 pin connector that has three wires going to it; This connector is for connecting to a PPM receiver, an S.Bus/SUMD/SUMH (Serial RX) receiver or for one channel of a PWM receiver. The remaining connectors are used for other PWM channels or IO signals.

The 4-pin JST-SH cables have bare ends because the UART1/2/I2C1/SWD connectors can be used to connect many devices, so you can cut to length and solder or crimp them as required

Unused wires can be removed from the JST-SH plugs. It is advisable to leave at least 3 wires in each JST-SH connector otherwise you risk damaging the cable when unplugging it.


IMPORTANT: Ensure that you leave some slack in your cable routing as this will help if you crash your aircraft.

Additional/replacement cable kits are available from your retailer.

Getting started

Verify flight controller operation via the configuration software.

- Disconnect the flight controller from your computer.
- Disconnect ALL connectors and headers from the flight controller.
- Install latest Silicon Labs CP2102 USB to UART Bridge VCP Drivers
<http://www.silabs.com/products/mcu/pages/usbtouartbridgevcpdrivers.aspx>
- Install and launch the Cleanflight Configurator tool
<https://chrome.google.com/webstore/detail/cleanflight-configurator/enacoimjcgiefnnpajinjgmkahmfgb>
- Connect flight controller to computer via USB cable.
- Select the correct COM port if it is not automatically detected.
- Click connect, verify that communication is established. (Fig 3)



[Figure 3 - Setup tab after connection established]

- Verify all sensors on your board are giving correct readings.



- Disconnect and **upgrade the firmware** using the Cleanflight configurator tool. (See Firmware Upgrade section)
For further software configuration see the getting started guide in the Cleanflight manual.


The basic steps, after firmware upgrade, are as follows.

- Choose board alignment - you can mount it in any orientation, not just with the arrow facing forwards.
- Calibrate sensors.
- Configure serial ports.
- Choose model/mixer (default is Quad X)
- Enable features.
- Configure receiver, set channel mapping.
- Configure channel mid and endpoints (1000-2000) and trim channels on transmitter.
- Configure voltage monitoring.
- Configure outputs (servos/ESCs)
- Ensure ESC calibration matches ESC configuration, recalibrate ESCs if needed.
- Learn about flight modes and configure channels/switches to activate them as required.
- Learn how to arm/disarm.
- Bench-test failsafe.
- Read safety notes.
- Learn how to download and view your flight logs to help tune your aircraft.
- Erase dataflash contents before first flight (so you have a log).
- Learn how to recognise un-tuned flight characteristics and the effects of a PID controller. (Watch some videos).
- First flight should be in Acro/Rate mode (the default mode when no other modes are active).
- Tune PIDs.
- Backup settings.
- Contribute to the Cleanflight project with feedback, suggestions, code, etc.

Firmware Upgrade

It is highly recommended that you immediately upgrade the firmware of the flight controller so that you have the latest features and bug fixes. **DO NOT FLY** until you have used the **latest firmware**.

1. Click the Firmware Flasher tab.
2. Select the latest SPRacingF3 stable release.
3. Set the flashing baud rate to 256000.
4. Click 'Load firmware [Online]' and wait for firmware to download and read release notes.
5. Click 'Flash Firmware'.



Troubleshooting

Q: It beeps continually.

A: Verify your RX is receiving data and your battery voltage monitoring is configured correctly.

Q: It have a problem not listed here.

A: Upgrade the firmware, try again, report issues via the forums.

Hardware Specifications

- 36x36mm board with 30.5mm mounting holes.
- ~5 grams.
- STM32F303 CPU with FPU 256kB flash.
- 8MB (64Mbit) High-Capacity Flash (Acro and Deluxe).
- MPU6050 accelerometer/gyro.
- MS5611 barometer (Deluxe only).
- HMC5883 magnetometer (Compass Sensor, Deluxe only).
- Micro USB socket.
- 4x 4pin JST-SH sockets (I2C, SWD, 2xUART).
- 2x 8pin JST-SH sockets (PPM, PWM, SERIAL RX, GPIO, ADC, 3V, 5V, GND).
- 8x 3pin though-holes for pin headers for ESC/Servo connections.
- 2x 4pin though-holes for pin headers for 2x serial ports.
- 2x 2pin though-holes for pin headers for battery voltage and buzzer.

Credits and acknowledgements

Hardware design by Dominic Clifton.

Manual by Dominic Clifton.

Seriously Pro website by Dominic Clifton.

Cleanflight firmware and GUI tools are maintained by Dominic Clifton.

Blackbox flight logging component and tools by Nicholas Sherlock.

The flight controller software is based on MultiWii by Alex Dubus.

The GUI tool was based on software by cTn.

Hardware project support and feedback by Romeo of MassiveRC.

Software support and contributions from many, many authors. For a complete list see github contributors.

<https://github.com/cleanflight/cleanflight/graphs/contributors>

Community

Thanks to everyone from the AWESOME Cleanflight community for code, artwork, support, ideas, feedback, and everything else. Without you all this product would not exist.