

# RX580s Instruction Manual

RX580s is a newly designed 5.8G wireless video receiver. The new design give the product elegant shape, super good performance, and humanized operation interface.

RX580s 是全新设计的 5.8G 无线接收机。具有功能出色，外形时尚，操作简单方便等特点。

RX580s come with button channel selector and LCD channel indicator that makes easy to select the channel.

Connect the power, long press 3seconds the Power/Channel button to power on the Receiver, long press again to switch off. Short press to select channel.

接上电源，长按电源/频道按键 3 秒开机，短按选择频道。再次长按关机。

## Product Picture (产品图片):



**Product Specification (产品规格):**

5.8GHz Double Output Receiver						
1	Video Format	NTSC/PAL				
2	Characteristics	Value			units	
3		Min	Typ	Max		
4	ANT Input Impedance		50		Ohm	
5	Video Output Channel		2			2 Buffer Output
	Video Output Level		1		Vp-p	75 ohm load
6	Audio Distortion		1	3.0	%	
	Audio Output Level		1.0	2	Vp-p	
7	Audio Subcarrier		6.5		MHz	
8	Sensitivity		-90		dbm	
9	Channel Frequency					
	CH1		5705		MHZ	
	CH2		5685		MHZ	
	CH3		5665		MHZ	
	CH4		5645		MHZ	
	CH5		5885		MHZ	
	CH6		5905		MHZ	
	CH7		5925		MHZ	
CH8		5945		MHZ		
10	Channel Switching	TACT Switch				7-seg Display
11	Operating Voltage(DC)	7		12.8	V	
12	Supply Current	190	200	220	mA	
13	SIZE	82*65*0.7			mm	
14	Weight	57			g	